




conga-SMX95 (Prototype Rev. Y.2)

Sample Distribution Set for congatec SMARC 2.2 Development

Quick Start Guide

Revision 1.01

Preface

This quick start guide provides information about the contents of the Sample Distribution Set for conga-SMX95 (Prototype Rev. Y.2) and how to set it up.

Software Licenses

Notice Regarding Open Source Software

The congatec products contain Open Source software that has been released by programmers under specific licensing requirements such as the "General Public License" (GPL) Version 2 or 3, the "Lesser General Public License" (LGPL), the "ApacheLicense" or similar licenses.

You can find the specific details at <https://www.congatec.com/en/licenses/>.

Enter the following command "license" in the bootloader to get the complete product related license information.

To the extent that any accompanying material such as instruction manuals, handbooks etc. contain copyright notices, conditions of use or licensing requirements that contradict any applicable Open Source license, these conditions are inapplicable. The use and distribution of any Open Source software contained in the product is exclusively governed by the respective Open Source license.

The Open Source software is provided by its programmers without ANY WARRANTY, whether implied or expressed, of any fitness for a particular purpose, and the programmers DECLINE ALL LIABILITY for damages, direct or indirect, that result from the use of this software.

congatec's liability with regards to the open source Software is as set out in congatec's Software License Information.

Disclaimer

The information contained within this quick start guide, including but not limited to any product specification, is subject to change without notice.

congatec GmbH provides no warranty with regard to this guide or any other information contained herein and hereby expressly disclaims any

implied warranties of merchantability or fitness for any particular purpose with regard to any of the foregoing. congatec GmbH assumes no liability for any damages incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and this guide. In no event shall congatec GmbH be liable for any incidental, consequential, special, or exemplary damages, whether based on tort, contract or otherwise, arising out of or in connection with this guide or any other information contained herein or the use thereof.

Intended Audience

This guide is intended for technically qualified personnel. It is not intended for general audiences.

RoHS Directive

All congatec GmbH designs comply with EU RoHS Directive 2011/65/EU and Delegated Directive 2015/863.

WEEE Directive



To comply with Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), ensure that this product is disposed of correctly at the end of its lifecycle. Customers are required to take electrical and electronic equipment to designated collection facilities separate from unsorted municipal waste, following applicable regional laws.

Proper disposal through designated collection points allows for the recycling, recovery, and reuse of valuable materials, supporting a more efficient use of resources and reducing environmental impact.



Note

Standalone congatec components, such as modules, carrier boards, and cooling solutions are designed to function only within other products. WEEE registration for the complete product must be completed by the entity placing the final product on the market.

Electrostatic Sensitive Device



All congatec GmbH products are electrostatic sensitive devices. They are enclosed in static shielding bags, and shipped enclosed in secondary

packaging (protective packaging). The secondary packaging does not provide electrostatic protection.

Do not remove the device from the static shielding bag or handle it, except at an electrostatic-free workstation. Also, do not ship or store electronic devices near strong electrostatic, electromagnetic, magnetic, or radioactive fields unless the device is contained within its original packaging. Be aware that failure to comply with these guidelines will void the congatec GmbH Limited Warranty.

Copyright Notice

Copyright © 2025, congatec GmbH. All rights reserved. All text, pictures and graphics are protected by copyrights. No copying is permitted without written permission from congatec GmbH.

congatec GmbH has made every attempt to ensure that the information in this document is accurate yet the information contained within is supplied "as-is".

Trademarks

Product names, logos, brands, and other trademarks featured or referred to within this guide, or the congatec website, are the property of their respective trademark holders. These trademark holders are not affiliated with congatec GmbH, our products, or our website.

Certification

congatec GmbH is certified to DIN EN ISO 9001 standard.



Warranty

congatec GmbH makes no representation, warranty or guaranty, express or implied regarding the products except its standard form of limited warranty ("Limited Warranty") per the terms and conditions of the congatec entity, which the product is delivered from. These terms and conditions can be downloaded from www.congatec.com. congatec GmbH may in its sole discretion modify its Limited Warranty at any time and from time to time.

The products may include software. Use of the software is subject to the terms and conditions set out in the respective owner's license agreements, which are available at www.congatec.com and/or upon request.

Beginning on the date of shipment to its direct customer and continuing for the published warranty period, congatec GmbH represents that the products are new and warrants that each product failing to function properly under normal use, due to a defect in materials or workmanship or due to non conformance to the agreed upon specifications, will be repaired or exchanged, at congatec's option and expense.

Customer will obtain a Return Material Authorization ("RMA") number from congatec GmbH prior to returning the non conforming product freight prepaid. congatec GmbH will pay for transporting the repaired or exchanged product to the customer.

Repaired, replaced or exchanged product will be warranted for the repair warranty period in effect as of the date the repaired, exchanged or replaced product is shipped by congatec, or the remainder of the original warranty, whichever is longer. This Limited Warranty extends to congatec's direct customer only and is not assignable or transferable.

Except as set forth in writing in the Limited Warranty, congatec makes no performance representations, warranties, or guarantees, either express or implied, oral or written, with respect to the products, including without limitation any implied warranty (a) of merchantability, (b) of fitness for a particular purpose, or (c) arising from course of performance, course of dealing, or usage of trade.

congatec GmbH shall in no event be liable to the end user for collateral or consequential damages of any kind. congatec shall not otherwise be liable for loss, damage or expense directly or indirectly arising from the use of the product or from any other cause. The sole and exclusive remedy against congatec, whether a claim sound in contract, warranty, tort or any other legal theory, shall be repair or replacement of the product only.

Technical Support

congatec GmbH technicians and engineers are committed to providing the best possible technical support for our customers so that our products can be easily used and implemented. We request that you first visit our website at www.congatec.com for the latest documentation, utilities and drivers, which have been made available to assist you. If you still require assistance after visiting our website then contact our technical support department by email at support@congatec.com

Revision History

Revision	Date (yyyy-mm-dd)	Author	Changes
1.00	2025-03-10	BEU	First Release
1.01	2025-11-20	RVI	Updated to prototype revision Y.2

1 Hardware

1.1 Sample Distribution Set

The hardware in the table below is included in the Sample Distribution Set:

Part #	Rev.	Name	Description
051691	Y.2	conga-SMX95/i-6C-4G eMMC64 DSI/NX611	SMARC Module with NXP i.MX 95 six-core processor. Features 6x ARM Cortex-A55 @ 1.8GHz + 1x ARM Cortex-M7 + 1x ARM Cortex-M33 + NPU, 4GB onboard LPDDR5 memory and 64GB onboard eMMC. Industrial grade temperature range from -40°C to 85°C. With MIPI-DSI. With Wifi/BT module NX611.
or			
051692	Y.2	conga-SMX95/i-6C-8G eMMC64	SMARC Module with NXP i.MX 95 six-core processor. Features 6x ARM Cortex-A55 @ 1.8GHz + 1x ARM Cortex-M7 + 1x ARM Cortex-M33 + NPU, 8GB onboard LPDDR5 memory and 64GB onboard eMMC. Industrial grade temperature range from -40°C to 85°C.
or			
051693	Y.2	conga-SMX95/i-6C-8G eMMC32 HDMI	SMARC Module with NXP i.MX 95 six-core processor. Features 6x ARM Cortex-A55 @ 1.8GHz + 1x ARM Cortex-M7 + 1x ARM Cortex-M33 + NPU, 8GB onboard LPDDR5 memory and 32GB onboard eMMC. Industrial grade temperature range from -40°C to 85°C. With DSI to HDMI Bridge.
051652	X.2	conga-SMX95/CSP-B	Passive cooling solution for SMARC Module conga-SMX95 with NXP i.MX 95 ARM processor. All standoffs are with 2.7mm bore hole.
or			
051653	X.2	conga-SMX95/HSP-B	Standard heatspreader for SMARC Module conga-SMX95 with NXP i.MX 95 ARM processor. All standoffs are with 2.7mm bore hole.
007010	C.2	conga-SEVAL	Evaluation carrier board for SMARC 2.0 modules.
or			
007010	D.4	conga-SEVAL	Evaluation carrier board for SMARC 2.1.1 modules.
48000023	A	Console Cable	MOLEX 6-Pin PicoBlade to two D-SUB 9
10000539	A	SD Card	MicroSDHC 32GB, SanDisk Ultra Class 10, U1, A1
N.A	1.0	Quick Start Guide	Quick Start Guide for conga-SMX95 (Rev. Y.2) Sample Distribution Set

Optional Accessories:

011115	B.0	conga-LDVI/EPI	LVDS to DVI converter board for digital flat panels with onboard EEPROM
033331	A	cab-LVDV-DAT-34-15	15 cm data cable LVDS to DVI adapter
052147	A	cab-LVDV-PWR-10-15	15 cm power cable LVDS to DVI adapter

1.2 conga-SMX95

For information about the planned conga-SMX95 Mass Production (MP) module variants, refer to the datasheet available at:

<https://www.congatec.com/us/products/smarc/conga-smx95/>

1.2.1 Pinout Description

The pinout description lists which signals of the NXP i.MX 95 processor are routed to the SMARC® connector. Use the link below to download the conga-SMX95 (Prototype Rev. Y.2) pinout as an Excel file:

https://git.congatec.com/arm-nxp/imx9-family-ea/doc/cgtimx95_pinlist



Note

Contact congatec support to get access to the pinout.

1.3 conga-SEVAL

The conga-SEVAL included in this prototype kit is an evaluation carrier board based on the SMARC® Specification.

For more information about the conga-SEVAL, refer to the datasheet or User's Guide available at:

www.congatec.com/us/products/accessories/conga-seval/

1.4 NXP i.MX 95

The NXP i.MX 95 processor documentation is available at:

<https://www.nxp.com/products/imx95>

1.5 Hardware Setup

1.5.1 With conga-SEVAL rev D.4

Follow the steps below to set up the hardware:

- 1. Ensure the hardware is protected from the effects of electrostatic discharge.
- 2. On the carrier board, set DIP switch M12.1 to OFF (Audio: I²S).
- 3. Set the NOR SPI-Flash as the boot source via DIP switches M18 and M17:

DIP M18	DIP M17		Boot Source ¹
M18.1	M17.2	M17.1	
OFF	ON	ON	NOR SPI-Flash

- 4. Insert the included SD card into the carrier microSD card slot X70 ².
- 5. Connect the console cable to the module connector X2.
- 6. Connect the console cable port labeled "CONSOLE" to your PC ³.
- 7. Mount the cooling solution onto the module (Final torque: 0.4 Nm).
- 8. Mount the module onto the carrier board (Final torque: 0.4 Nm).
- 9. Connect your monitor to one of the display interfaces of your module:


Part #	Display Interface ^{4, 5}		Carrier Connector
051691	MIPI-DSI	LVDS0	X23, X26 (power)
051692	DisplayPort (DP)	LVDS0, LVDS1	X33 (upper port)
051693	HDMI	LVDS0, LVDS1	X33 (lower port)

- 11. Connect your ATX Power Supply Unit (PSU) to the carrier board.
- 12. To start the system, switch the ATX PSU on.



Note

- 1. The boot source selection does not conform to the SMARC specification.
- 2. Yocto Linux is pre-installed on the included SD card.
- 3. Optionally, use an USB to Serial RS-232 adapter (not included).
- 4. Optionally, congatec offers an LVDS to DVI converter board with matching power and data cables—see section 1.1 "Sample Distribution Set".
- 5. Other supported display interfaces require changes to the device tree.



1.5.2 With conga-SEVAL rev C.2

Follow the steps below to set up the hardware:

- 1. Ensure the hardware is protected from the effects of electrostatic discharge.
- 2. On the carrier board, set DIP switch M12.1 to OFF (Audio: I²S).
- 3. Set the NOR SPI-Flash as the boot source via DIP switches M18 and M17:

DIP M18		DIP M17		Boot Source ¹
M18.1		M17.2	M17.1	
OFF		ON	ON	NOR SPI-Flash

- 4. Insert the included SD card into the carrier SD card slot CN1 ².
- 5. Connect the console cable to the module connector X2.
- 6. Connect the console cable port labeled "**CONSOLE**" to your PC ³.
- 7. Mount the cooling solution onto the module (Final torque: 0.4 Nm).
- 8. Mount the module onto the carrier board (Final torque: 0.4 Nm).
- 9. Connect your monitor to one of the display interfaces of your module:

Part #	Display Interface ^{4, 5}		Carrier Connector
051691	MIPI-DSI	LVDS0	X23, X26 (power)
051692	DisplayPort (DP)	LVDS0, LVDS1	X33 (upper port)
051693	HDMI	LVDS0, LVDS1	X33 (lower port)


- 10. Connect your ATX Power Supply Unit (PSU) to the carrier board.
- 11. To start the system, switch the ATX PSU on.



conga-SEVAL Rev. C.2 is compliant with SMARC 2.0 and may not support several features introduced in SMARC 2.1 and later. For this reason, the use of the conga-SEVAL Rev. D.4 is recommended.



- 1. The boot source selection does not conform to the SMARC specification.
- 2. Yocto Linux is pre-installed on the included SD card.
- 3. Optionally, use an USB to Serial RS-232 adapter (not included).
- 4. Optionally, congatec offers an LVDS to DVI converter board with matching power and data cables—see section 1.1 "Sample Distribution Set".
- 5. Other supported display interfaces require changes to the device tree.



2 Software

The software for the conga-SMX95 is available at:

<https://git.congatec.com/arm-nxp/imx9-family-ea/>



Note

Contact congatec support to get access to the repository.

2.1 Operating System

By default, the system boots the operating system that is stored on the SD card. Yocto Linux is preinstalled on the included SD card. ^{1,2}



Note

1. Booting to a graphical user interface (GUI) may take some time. This is because the complete system initialization occurs from the SD card connected via a 4-bit interface.
2. In order to maintain the integrity of the file system, it is recommended to always shut down the system by issuing the command "poweroff" in the console terminal.

2.2 Starting Up

The conga-SMX95 uses U-boot as standard bootloader. The bootloader is GNU GPL open source software. A serial terminal connection is required in order to display the boot process and to modify the boot behavior. The boot behavior is controlled via environment variables.

To establish a terminal connection, a terminal program such as TeraTerm or Putty can be used.

Use the following communication parameters:

Baud rate:	115200
Data:	8 bit
Parity:	none
Stop:	1 bit
Flow control:	none

2.3 Boot Process

The conga-SMX95 boot process starts at Power On Reset (POR), where the hardware reset logic forces the ARM core to begin execution, starting from the on-chip boot ROM of the processor.

After loading, the bootloader will be executed and will perform basic system initialization (e.g. the system memory, serial console, etc.). Afterwards, the environment settings are parsed and the system boot will go ahead as specified.

Press any key during startup to stop autoboot and to get to u-boot console. At the u-boot console, the environment settings can be displayed using the "print" command. In addition, useful functionality is available (such as memory dump, access to the SPI and the I2C system, etc.). The "help" command will display any command supported by the u-boot.

If autoboot is not interrupted by pressing a key, the boot process goes ahead and the module will boot the operating system that is installed on the SD card.

2.4 U-Boot Environment Variables

The u-boot environment of the conga-SMX95 (Prototype Rev. Y.2) is stored on the NOR SPI-Flash. One of the benefits of the u-boot bootloader is the possibility to specify its run time configuration using environment variables.

The environment variables of u-boot can be displayed using the printenv (or the print) command.

During the boot process, the bootloader evaluates the "bootcmd" variable and executes it. The boot command tries to load a bootscript or a kernel from the boot device. If this is successful, the script or kernel will be started, otherwise a fallback to network boot is performed. The variable "mmcdev" specifies the mmc boot device. Furthermore, the variable "mmcroot" is passed to the kernel in order to specify the location of the root filesystem.