



# congatec Application Note #21

Affected Products	All congatec CPU modules and SBCs			
Subject	Create and add OEM Activation table to a congatec BIOS			
Confidential/Public	Public			
Author	GMA			



# **Revision History**

Revision	Date (yyyy-mm-dd)	Author	Changes
1.0	2011- 06-16	CJR	Initial release
1.1	2016-11-08	GMA	Added sections 5 and 6 and updated section 1 and 7 to include information about OEM Activation 3.0.



### **Preface**

This Application Note provides information and an example about how to create and add an OEM ACPI SLIC table (OA2.1) module or an OEM OA 3.0 ACPI MSDM table module into the BIOS of a congatec CPU module.

#### Disclaimer

The information contained within this Application Note, including but not limited to any product specification, is subject to change without notice.

congatec AG provides no warranty with regard to this Application Note or any other information contained herein and hereby expressly disclaims any implied warranties of merchantability or fitness for any particular purpose with regard to any of the foregoing. congatec AG assumes no liability for any damages incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and the Application Note. In no event shall congatec AG be liable for any incidental, consequential, special, or exemplary damages, whether based on tort, contract or otherwise, arising out of or in connection with this Application Note or any other information contained herein or the use thereof.

#### **Intended Audience**

This Application Note is intended for technically qualified personnel. It is not intended for general audiences.

#### **Electrostatic Sensitive Device**

All congatec AG products are electrostatic sensitive devices and are packaged accordingly. Do not open or handle a congatec AG product except at an electrostatic-free workstation. Additionally, do not ship or store congatec AG products near strong electrostatic, electromagnetic, magnetic, or radioactive fields unless the device is contained within its original manufacturer's packaging. Be aware that failure to comply with these guidelines will void the congatec AG Limited Warranty.

### **Technical Support**

congatec AG technicians and engineers are committed to providing the best possible technical support for our customers so that our products can be easily used and implemented. We request that you first visit our website at www.congatec.com for the latest documentation, utilities and drivers, which have been made available to assist you. If you still require assistance after visiting our website then contact our technical support department by email at support@congatec.com



#### **Symbols**

The following are symbols used in this application note.



Notes call attention to important information that should be observed.



Caution

Cautions warn the user about how to prevent damage to hardware or loss of data.



Warning

Warnings indicate that personal injury can occur if the information is not observed.

### **Copyright Notice**

Copyright © 2016, congatec AG. All rights reserved. All text, pictures and graphics are protected by copyrights. No copying is permitted without written permission from congatec AG.

congatec AG has made every attempt to ensure that the information in this document is accurate yet the information contained within is supplied "as-is".

#### **Trademarks**

Product names, logos, brands, and other trademarks featured or referred to within this user's guide or the congatec website, are the property of their respective trademark holders. These trademark holders are not affiliated with congatec AG, our products, or our website.



### **Terminology**

Description
Advanced Configuration and Power Interface
Software Licensing
OEM Activation
Certificate of Authenticity
Windows Product Activation
System-Locked Pre-installation
Digital Product Key
Software Development Kit
Microsoft Data Management



## **Contents**

1	lr	Introduction	
2	C	Create a ACPI_SLIC table	8
	2.1		
	2.2	OEM Public Key (OA20PubKey.bin)	9
	2.3		
	2.4		
3	Д	Add an OEM SLIC table to BIOS Binary file	<u></u>
4	Т	Test	1
5	C	Create an OA 3.0 ACPI_MSDM table	15
6	А	Add an OA 3.0 ACPI_MSDM table to BIOS Binary file	15
7	C	CGUTLCMD Command Line Version	19
8		Additional Information	



## 1 Introduction

OEM Activation technology allows system integrators to activate licensed copies of a Windows Operating System (OS). Therefore, end users of the embedded system do not have to activate the OS.

When OEM Activation 2.1 or OEM Activation 3.0 is properly installed and set up, activating the Windows OS (Windows Product Activation) is no longer necessary.

OA3.0 is supported by Windows 8 and Windows 10.

OA2.1 is supported by Windows Vista, Windows 7 and Windows Server 2008.

OA1.0, also known as SLP, is available for Windows XP and Windows Server 2003.

This application note does not explain what OA2.1 and OA3.0 is and how they work. OEMs using this technology have access to Microsoft white papers covering this in detail.

This application note provides information about how to implement OEM Activation 2.1 and 3.0 on congatec embedded PC modules and SBCs using the CGUTIL utility and gives a step by step example of such a BIOS binary modification.



The congatec CGUIL utility can also be used by OEMs to add their SLP string for the Windows XP activation to the congatec embedded BIOS. The process is not described in this AN, contact congatec support for further information about integrating a SLP string to the BIOS.



## 2 Create a ACPI\_SLIC table

The ACPI\_SLIC table contains the key that is proprietary to and exclusively for the Windows OEM Activation 2.1 solution. The table must be added to the systems BIOS as a standard ACPI System Description Table. congatec has included a special BIOS feature into its embedded BIOS that allows customers to add this table by themselves using the congatec CGUTIL BIOS configuration utility.

### 2.1 Layout of the ACPI\_SLIC table

Field	Byte Length	Byte Offset	Description
Signature	4	0	"SLIC"
Length	4	4	Length of the table in bytes
Revision	1	8	1
Checksum	1	9	Checksum of the SLIC table, sum must be zero
OEMID	6	10	OEM supplied string that identifies the OEM
OEM Table ID	8	16	OEM supplied string to identify the table data
OEM Revision ID	4	24	OEM supplied revision number
Creator ID	4	28	Vendor ID of the utility that created the table
Creator Revision	4	32	Revision of the utility that created the table
SLIC public key structure	156	36	Public key binary data file (OA20PubKey.bin) that is created by OATool.exe
SLIC Windows marker structure	182	192	Windows marker binary data file (OA20Marker.bin) that is created by OATool.exe

The first 36 bytes (colored) are the standard header of an ACPI system description table. All this information is automatically added by the congatec BIOS during APCI table initialization during boot-up so this part will not be further discussed here.

The two following structures are provided to the OEM by Microsoft or created by the OEM with a Microsoft tool named OATool.exe. These two binaries are very important when creating the ACPI\_SLIC table for OA2.1.



### 2.2 OEM Public Key (OA20PubKey.bin)

The 1024 bit RSA key (file name: OA20Pubkey.bin) is used to verify the signature of the Windows marker.

### 2.3 Windows Marker (OA20Marker.bin)

The Windows marker is a Microsoft proprietary digital certificate that contains OEM identifying information signed with an OEM's private key.

#### 2.4 OEM SLIC Table

Use a hex editor of your choice to copy the two data structures into one binary file. The OEM public key binary (OA20PubKey.bin) must be the first one.

In DOS you can easily perform a binary copy of the two files using this command:

copy /b OA20PubKey.bin + OA20Marker.bin OEMSLIC.bin

OEMSLIC.bin is the input file for CGUTIL when adding an OEM SLIC table. See below.

## 3 Add an OEM SLIC table to BIOS Binary file


Creating an "OEM SLIC table module" and inserting it into a BIOS binary file can be done using the congatec System Utility.

The following tutorial describes the procedure step-by-step based on a Windows 10 Enterprise host system. All changes will be done to the BIOS binary file.

Following these steps will create a modified BIOS binary file that can be used to update congatec CPU modules and SBCs (in this example: "OEM1R001.bin"). The original BIOS binary file will not be modified by the congatec System Utility.

For more information about the BIOS update process, refer to the application note "AN01\_BIOS\_Update.pdf," which can be found on congatec website.







- Open the "congatec System Utility."
- Select "BIOS File" as operating target.
- Push the button "Select Input BIOS File."




- Browse for your designated BIOS BIN file.
- Click "Select original/Create new BIOS file."



- Enter a file name (in this example "OEM1R001.bin")
- Changes will be applied only to this file. The original BIOS binary file will remain unchanged.
- Click on the "BIOS Module Modification" button.








- Click on the "Create Module" button.



- Browse for your binary OEM SLIC table file created previously in section 2.4 (in this example "oemslic.bin").




- Choose "OEM SLIC Table" from the "Module Type" drop down list.
- Leave the Module ID and Module Revision field unchanged.
- Once this is completed, click on "Create Module" button.





- Chose your designated module file name (in this example "oemslic.mod").




- Click on "Add Module" button.



- Browse for the module that was created earlier ("oemslic.mod").






- The designated OEM SLIC Table module must be visible in the list of modules.
- Click on "Apply" to save the changes into the BIOS binary file.
- "Changes successfully applied" will be displayed in red letters in the text box above the "Apply" button.

Once these steps are completed, the "BIOS Module Modification" window can be closed by clicking on the "Close" button and proceed with closing the main window of the congatec System Utility by clicking on the "Close" button again.



### 4 Test

Download the SLIC ToolKit utility from the Internet and run it on the target system before and after flashing the new BIOS supporting OA2.1. The utility provides the status about the ACPI SLIC table implementation.



This test can be performed without having the target Windows operating system.

There are additional tests with the target Windows operating system described in the Microsoft Whitepaper "OEM Activation 2.1 for Windows Operating Systems".



## 5 Create an OA 3.0 ACPI\_MSDM table

The OA 3.0 ACPI\_MSDM table contains the key that is proprietary to and exclusively for the Windows OEM Activation 3.0 solution. The table must be added to the systems BIOS as a standard ACPI System Description Table. congatec has included a special BIOS feature in the embedded BIOS allowing customers to add this table by themselves with the congatec CGUTIL BIOS configuration utility.

The Microsoft Tool OA30TOOl.exe creates the OA 3.0 ACPI\_MSDM with the Digital Product Key.

OEMs should contact their Microsoft support for further information about the OA 3.0 tools and activation process.

# 6 Add an OA 3.0 ACPI\_MSDM table to BIOS Binary file

Use the congatec System Utility revision 1.5.6 or newer to insert the OA 3.0 ACPI\_MSDM table module into the BIOS binary file.

The following tutorial describes the procedure step-by-step based on a Windows 10 Enterprise host system. All changes will be done to the BIOS binary file.

Following these steps will create a modified BIOS binary file that can be used to update congatec CPU modules (in this example: "OEM1R001.bin"). The original BIOS binary file will not be modified by the congatec System Utility.


For more information about the BIOS update process, refer to the application note "AN01\_BIOS\_Update.pdf," available on the congatec website.

OA 3.0 is a new feature not supported by older congatec BIOS versions. Check with your congatec support whether your BIOS supports this method.






- Open the "congatec System Utility."
- Select "BIOS File" as operating target.
- Push the button "Select Input BIOS File."




- Browse for your designated BIOS BIN file.
- Click "Select original/Create new BIOS file."




- Enter a file name (in this example "OEM1R001.bin")
- Changes will be applied only to this file. The original BIOS BIN file will remain unchanged.
- Click on the "BIOS Module Modification" button.








- Click on the "Create Module" button.




- Browse for your binary OEM MSDM table file created previously in section 5 (in this example "oa30msdm.bin").




- Choose "OA 3.0 Module" from the "Module Type" drop down list.
- Leave the Module ID and Module Revision field unchanged.
- Once this is completed, click on "Create Module" button.





- Chose your designated module file name (in this example "oa30msdm.mod").




- Click on "Add Module" button.



- Browse for the module created earlier ("oa30msdm.mod").





- The designated OA 3.0 module must be visible in the list of modules.
- Click on "Apply" to save the changes into the BIOS BIN file.
- "Changes successfully applied" will be displayed in red letters in the text box above the "Apply" button.

Once these steps are completed, close the "BIOS Module Modification" window by clicking on the "Close" button and then close the main window of the congatec System Utility by clicking on the "Close" button.

### 7 CGUTLCMD Command Line Version

OEM Activation 3.0 removes the need for a COA product key by utilizing a unique DPK. It is used to verify the genuine license of each Windows system during activation. Each OA 3.0 DPK may be only distributed with a single OEM system. Using an OA 3.0 DPK on multiple systems is not allowed.

Due to this, the OA 3.0 ACPI\_MDSM table and contents (including a unique DPK) must be added to each PC's BIOS separately. The preferred way to do this is by using a type of script processing that utilizes CGUTLCMD, the command line version of congatec's System Utility.

Here is an example of how the command line tool can be used in MS-DOS or the UEFI Shell:

It is assumed that all necessary files are added to the working directory or a reference to the absolute path.

Run the following commands to create and add an OA 3.0 module to the onboard BIOS flash.

To create a module run:

cgutlcmd module /ot:board /create /if: oa30msdm.bin /of: oa30msdm.mod /t:14

To add a module run:

cgutlcmd module /ot:board /add /if: oa30msdm.mod

On the next boot of the system the OA3.0 MSDM ACPI table will be applied.



## 8 Additional Information

Document	Source
Whitepaper: OEM Activation 2.1 for Windows Operating Systems	Microsoft
Whitepaper: OEM Activation 3 for Windows Operating Systems	Microsoft
OEM Activation 2.1 Tools Users Guide	Microsoft
OEM Activation 2.1 Frequently Asked Questions	Microsoft
ACPI Specification	http://www.uefi.org/specifications
congatec System Utility CGUTIL	www.congatec.com
congatec Application Notes	www.congatec.com/supp-appnotes.html